
DE

Lock Key Basic


Bedienungsanleitung

SMARTKEEPER ESSENTIAL

Lock Key Basic




1. Schlüsselkopf; 2. Taste; 3. Körper; 4. Abdeckung; 5. Lasche; 6. Einsteck-/Abziehmodus; 7. Ausziehmodus; 8. Aufbewahrungsmodus



Mit Lock Key Basic kompatible Produkte
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Verwendung von Lock Key Basic



1. Einsteck-/Abziehmodus: Schieben Sie die Abdeckung nach hinten und die Taste nach vorn. In diesem Modus können Sie den Schlüssel in die Sperre einstecken oder nur den Schlüssel aus der Sperre abziehen.

2. Ausziehmodus: Schieben Sie bei eingestecktem Schlüssel die Taste nach hinten, damit der Schlüssel die Sperre zum Entfernen greift. Ziehen Sie anschließend am Schlüssel, um die Sperre aus dem Anschluss zu entfernen.

3. Aufbewahrungsmodus: Schieben Sie die Abdeckung bei Nichtgebrauch vollständig nach vorn, um den Schlüsselkopf zu schützen.

Vorsichtsmaßnahmen

Stecken Sie den Schlüssel vorsichtig, in der richtigen Richtung und vollständig ein. Vergewissern Sie sich vor dem Entfernen der Sperre, dass der Schlüssel vollständig greift. Halten Sie den Schlüssel an den Seiten fest, wenn Sie die Abdeckung zurückschieben, und achten Sie darauf, sich nicht am Schlüsselkopf die Hand einzuklemmen. Schlüssel und Sperre müssen dieselbe Farbe haben.

SMARTKEEPER ESSENTIAL — Produktübersicht

Produktreihe für Lock Key Basic
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Produktreihe für Lock Key Mini
USB-B Port Lock, Mini USB-B Port Lock, Micro USB-B Port Lock, USB-C Port Lock, SD Port Lock, CF Port Lock, RJ11 Port Lock, HDMI Port Lock, DisplayPort Lock, Mini DisplayPort Lock.

Kein Schlüssel erforderlich
USB Closing Lock, LAN Cable Grip, Power Cord Lock, Power Extension Cord Lock, PC Lock (Combination), Laptop Lock (Combination), Laptop Lock Plus (Combination), SMARTKEEPER Multi Hub, Laptop DOCK & LOCK, Mouse Holder, RJ45 Dust Cover.

Komplett-Sicherheitspakete
PC Port Secure Pack, Server Port Secure Pack.

Schlüssel
Lock Key Basic, Lock Key Mini.

www.smartkeeper.de


EN

Lock Key Basic


User guide

SMARTKEEPER ESSENTIAL

Lock Key Basic




1. Key head; 2. Button; 3. Body; 4. Cover; 5. Tab; 6. Insert Mode; 7. Retrieval Mode; 8. Storage Mode



Compatible products with Lock Key Basic
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

How to use Lock Key Basic



1. Insert Mode: Slide the cover backward and the button forward. In this mode, insert the key into the lock or withdraw only the key from the lock.

2. Retrieval Mode: With the key inserted, slide the button backward to engage the lock for removal. Then pull the key to remove the lock from the port.

3. Storage Mode: When not in use, slide the cover fully forward to protect the key head.

Precautions

Insert the key carefully, fully and in the correct direction. Make sure it is fully engaged before removing the lock. Hold the sides of the key when sliding the cover backward, and take care not to pinch your hand against the key head. The key and lock must be the same color.

SMARTKEEPER ESSENTIAL — Line-up

Lock Key Basic Line-up
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Lock Key Mini Line-up
USB-B Port Lock, Mini USB-B Port Lock, Micro USB-B Port Lock, USB-C Port Lock, SD Port Lock, CF Port Lock, RJ11 Port Lock, HDMI Port Lock, DisplayPort Lock, Mini DisplayPort Lock.

No Key Required
USB Closing Lock, LAN Cable Grip, Power Cord Lock, Power Extension Cord Lock, PC Lock (Combination), Laptop Lock (Combination), Laptop Lock Plus (Combination), SMARTKEEPER Multi Hub, Laptop DOCK & LOCK, Mouse Holder, RJ45 Dust Cover.

All-in-one security packs
PC Port Secure Pack, Server Port Secure Pack.

Lock keys
Lock Key Basic, Lock Key Mini.

www.smartkeeper.de


ES

Lock Key Basic


Guía de uso

SMARTKEEPER ESSENTIAL

Lock Key Basic




1. Cabezal de la llave; 2. Botón; 3. Cuerpo; 4. Cubierta; 5. Pestaña; 6. Modo inserción; 7. Modo extracción; 8. Modo almacenamiento



Productos compatibles con Lock Key Basic
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Cómo utilizar Lock Key Basic



1. Modo inserción: Deslice la cubierta hacia atrás y el botón hacia delante. En este modo puede introducir la llave en el bloqueo o retirar únicamente la llave del bloqueo.

2. Modo extracción: Con la llave insertada, deslice el botón hacia atrás para que la llave sujete el bloqueo. Después tire de la llave para extraer el bloqueo del puerto.

3. Modo almacenamiento: Cuando no utilice la llave, deslice la cubierta completamente hacia delante para proteger el cabezal.

Precauciones

Introduzca la llave con cuidado, completamente y en la orientación correcta. Compruebe que esté totalmente enganchada antes de retirar el bloqueo. Sujete la llave por los lados al deslizar la cubierta hacia atrás y tenga cuidado de no pillarse la mano con el cabezal. La llave y el bloqueo deben ser del mismo color.

SMARTKEEPER ESSENTIAL — Gama de productos

Gama para Lock Key Basic
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Gama para Lock Key Mini
USB-B Port Lock, Mini USB-B Port Lock, Micro USB-B Port Lock, USB-C Port Lock, SD Port Lock, CF Port Lock, RJ11 Port Lock, HDMI Port Lock, DisplayPort Lock, Mini DisplayPort Lock.

No requiere llave
USB Closing Lock, LAN Cable Grip, Power Cord Lock, Power Extension Cord Lock, PC Lock (Combination), Laptop Lock (Combination), Laptop Lock Plus (Combination), SMARTKEEPER Multi Hub, Laptop DOCK & LOCK, Mouse Holder, RJ45 Dust Cover.

Paquetes de seguridad todo en uno
PC Port Secure Pack, Server Port Secure Pack.

Llaves
Lock Key Basic, Lock Key Mini.

www.smartkeeper.de


FR

Lock Key Basic


Guide d’utilisation

SMARTKEEPER ESSENTIAL

Lock Key Basic




1. Tête de clé; 2. Bouton; 3. Corps; 4. Couvercle; 5. Languette; 6. Mode insertion; 7. Mode extraction; 8. Mode rangement



Produits compatibles avec Lock Key Basic
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Utilisation de Lock Key Basic



1. Mode insertion : faites glisser le couvercle vers l’arrière et le bouton vers l’avant. Ce mode permet d’insérer la clé dans le verrou ou de retirer uniquement la clé du verrou.

2. Mode extraction : avec la clé insérée, faites glisser le bouton vers l’arrière pour que la clé saisisse le verrou. Tirez ensuite sur la clé pour retirer le verrou du port.

3. Mode rangement : lorsque la clé n’est pas utilisée, faites glisser le couvercle complètement vers l’avant pour protéger la tête de clé.

Précautions

Insérez la clé avec précaution, complètement et dans le bon sens. Vérifiez qu’elle est bien engagée avant de retirer le verrou. Tenez la clé par les côtés lorsque vous faites glisser le couvercle vers l’arrière et veillez à ne pas vous pincer la main contre la tête de clé. La clé et le verrou doivent être de la même couleur.

SMARTKEEPER ESSENTIAL — Gamme de produits

Gamme pour Lock Key Basic
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Gamme pour Lock Key Mini
USB-B Port Lock, Mini USB-B Port Lock, Micro USB-B Port Lock, USB-C Port Lock, SD Port Lock, CF Port Lock, RJ11 Port Lock, HDMI Port Lock, DisplayPort Lock, Mini DisplayPort Lock.

Sans clé
USB Closing Lock, LAN Cable Grip, Power Cord Lock, Power Extension Cord Lock, PC Lock (Combination), Laptop Lock (Combination), Laptop Lock Plus (Combination), SMARTKEEPER Multi Hub, Laptop DOCK & LOCK, Mouse Holder, RJ45 Dust Cover.

Packs de sécurité tout-en-un
PC Port Secure Pack, Server Port Secure Pack.

Clés
Lock Key Basic, Lock Key Mini.


www.smartkeeper.de

IT Lock Key Basic


Manuale d’uso

SMARTKEEPER ESSENTIAL

Lock Key Basic




1. Testa della chiave; 2. Pulsante; 3. Corpo; 4. Copertura; 5. Linguetta; 6. Modalità inserimento; 7. Modalità estrazione; 8. Modalità conservazione



Prodotti compatibili con Lock Key Basic
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Come utilizzare Lock Key Basic



1. Modalità inserimento: far scorrere la copertura all’indietro e il pulsante in avanti. In questa modalità è possibile inserire la chiave nel blocco o rimuovere soltanto la chiave dal blocco.

2. Modalità estrazione: con la chiave inserita, far scorrere il pulsante all’indietro affinché la chiave agganci il blocco. Tirare quindi la chiave per rimuovere il blocco dalla porta.

3. Modalità conservazione: quando la chiave non viene utilizzata, far scorrere la copertura completamente in avanti per proteggere la testa della chiave.

Precauzioni

Inserire la chiave con attenzione, completamente e nel verso corretto. Verificare che sia completamente agganciata prima di rimuovere il blocco. Tenere la chiave dai lati quando si fa scorrere la copertura all’indietro e fare attenzione a non pizzicarsi la mano contro la testa della chiave. La chiave e il blocco devono essere dello stesso colore.

SMARTKEEPER ESSENTIAL — Gamma di prodotti

Gamma per Lock Key Basic
USB Port Lock, USB Cable Lock, Keyboard/Mouse Lock, Lockable Flash Drive, Smart Data Blocker, RJ45 Port Lock, LAN Cable Lock 2, Secure LAN Cable Coupler, Network Module Lock 4/8/12P, Serial Port Lock, DVI Port Lock, Parallel Port Lock.

Gamma per Lock Key Mini
USB-B Port Lock, Mini USB-B Port Lock, Micro USB-B Port Lock, USB-C Port Lock, SD Port Lock, CF Port Lock, RJ11 Port Lock, HDMI Port Lock, DisplayPort Lock, Mini DisplayPort Lock.

Non richiede chiave
USB Closing Lock, LAN Cable Grip, Power Cord Lock, Power Extension Cord Lock, PC Lock (Combination), Laptop Lock (Combination), Laptop Lock Plus (Combination), SMARTKEEPER Multi Hub, Laptop DOCK & LOCK, Mouse Holder, RJ45 Dust Cover.

Pacchetti di sicurezza tutto in uno
PC Port Secure Pack, Server Port Secure Pack.

Chiavi
Lock Key Basic, Lock Key Mini.

www.smartkeeper.de